



[Baza Wiedzy](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Aura](#) > [Jak ładować głośnik Classic Aura i sprawdzać stan baterii?](#)

## Jak ładować głośnik Classic Aura i sprawdzać stan baterii?

Customer Support - 2025-08-08 - [Classic Aura](#)

### Chcesz naładować urządzenie Classic Aura i sprawdzić stan baterii?

1. Klasyczny model Aura wymaga ładowarki USB-C o mocy od 5 W do 30 W.

Aby uzyskać optymalną prędkość ładowania i maksymalną głośność podczas ładowania, wymagana jest moc 30 W.

1. Podłącz głośnik do ładowarki USB-C.

Podczas ładowania będzie migać ikona Eco (bateria).

1. Po naładowaniu do 100% ikona Eco (bateria) przestanie migać.

Stan ładowania można również sprawdzić podczas słuchania, naciskając przycisk Eco przez 2 sekundy.

4 diody LED nad pokrętką głośności będą świecić, wskazując aktualny stan baterii.



| Battery level |      | LED Behavior |       |       |       | Illustration |
|---------------|------|--------------|-------|-------|-------|--------------|
| From          | To   | LED1         | LED2  | LED3  | LED4  |              |
| 75%           | 100% | high         | high  | high  | blink |              |
| 45%           | 75%  | high         | high  | blink | off   |              |
| 25%           | 45%  | high         | blink | off   | off   |              |
| 5%            | 25%  | high         | off   | off   | off   |              |
| 0%            | 5%   | blink        | off   | off   | off   |              |

| Battery level |      | LED Behavior |       |       |       | Illustration |
|---------------|------|--------------|-------|-------|-------|--------------|
| From          | To   | LED1         | LED2  | LED3  | LED4  |              |
| 95%           | 100% | on           | on    | on    | on    |              |
| 75%           | 95%  | on           | on    | on    | pulse |              |
| 45%           | 75%  | on           | on    | pulse | off   |              |
| 25%           | 45%  | on           | pulse | off   | off   |              |
| 0%            | 25%  | pulse        | off   | off   | off   |              |